




MOTOROLA

User's Guide
Guide de l'utilisateur

TALKABOUT™
NUMERIC PAGER



Model T10
FLEX™ Technology
Modèle T10
Technologie FLEX^{MC}

Contents

Introduction	1
Effective Use of Your Pager	1
Getting Started	2
Battery Information.....	2
Installing/Replacing the Battery	2
Control Buttons	4
Turning Your Pager On	5
Turning Your Pager Off.....	5
Sending a Test Page to Yourself.....	6
Backlight	7
Using the Main Menu.....	8
Status Indicators	8
Time and Date	9
Setting the Time	9
Setting the Date.....	9
Displaying the Date.....	10
Setting the Alarm	11
Alerts	12
Setting the Alert Type	12
Reminder Alert	13
Low Cell Alert.....	13
Messages	15
Reading Messages.....	15
Locking/Unlocking Messages	16
Message Information	16
Deleting Messages	17
Care & Maintenance	18
Cleaning Your Pager	19
Questions	20
FCC Compliance	21

Introduction

Congratulations on your purchase of your Talkabout™ T10 pager.

This booklet contains operation instructions that explain how to use your new pager and provides helpful suggestions for first-time as well as experienced users.

Effective Use of Your Pager

Your pager can help you keep in contact with everyone important to you. By giving your pager number to business associates, family, and friends, you can be contacted whenever needed.



Getting Started

Battery Information

Your pager operates with a single AAA-size alkaline battery (do not use carbon zinc batteries). See the diagram on the following page for the battery door location.

If **LOW BATT** displays, the pager's AAA-size battery is low. Replace the AAA-size battery.

Installing/Replacing the Battery

- 1 Holding the pager face down, slide the battery door in the direction of the arrow (toward the outer edge).
- 2 Lift the battery door away from the pager's housing to remove it.
- 3 Remove the old battery, noting the positive (+) and negative (-) polarity markings.
- 4 Insert a new battery so the polarity markings on the battery match the polarity diagram in the battery compartment.

- 5 Replace the battery door.




CAUTION!

Note the (+) and (-) polarity markings. Do not insert the battery backwards, or all messages will be erased.



Control Buttons



Function: Press to move between features and change values.




Select/Backlight: Press to select features and turn on/off the backlight.




Read/Escape: Press to read messages or return to the Status screen.



Turning Your Pager On

- 1 Ensure that a fresh battery is properly installed as listed in “Installing/Replacing the Battery” on page 2.
- 2 Press and hold  for 3 to 4 seconds to turn your pager on. The Status screen displays.



When the pager is on and no activity is taking place, the Status screen displays. The Status screen displays the power-on indicator and may also display other pager status indicators.

Turning Your Pager Off


Press  until *PAGER OFF* displays, and then press .



Sending a Test Page to Yourself

It's a good idea to test your pager and service by sending a page to yourself. Start by using the phone number, web site, or email address (and a PIN, if required) your service provider gave you, then enter a short message. If you are sending a word message from a phone, an operator will assist you; otherwise, press the phone buttons to enter a numeric message or type a message and send it. While you are waiting for the message to reach your pager, refer to page 15 for information about how to read a message. If your pager does not receive the message within a few minutes, contact your service provider. After you've tested the pager, read the rest of this guide to learn about the many useful features of your new pager.

Backlight




In low-light conditions, you can turn on the pager's backlight on or off at any time by pressing and holding  for two seconds. The backlight automatically turns off when the pager returns to the Status screen.














Using the Main Menu

The main menu provides access to the many features of your pager through the use of symbols and prompts.

- 1 To navigate through the main menu, press .
- 2 Press  to select the displayed feature.
- 3 Press  at any time to return to the Status screen.

Status Indicators



The list below describes each of the status indicators that may display on your pager.


-  New message
-  Musical alert
-  Silent alert
-  Alarm
-  Locked message
-  Duplicate message
-  Out-Of-Range alert
-  Continuous message (press  to display the next screen.)






Time and Date



Setting the Time


- 1 From the Status screen, press  until **SET TIME** displays, and then press .






- 2 Press  to increase the hour. When the desired hour displays, press  to advance to the next field.
- 3 Repeat Step 2 to set the minutes and time of day (AM or PM).
- 4 When you have finished setting the time, press  to save your changes and return to the Status screen.

Setting the Date

- 1 From the Status screen, press  until **SET DATE** displays, and then press .







- 2 Press  to increase the year. When the desired year displays, press .
- 3 Repeat Step 2 to set the month/day.
- 4 When you have finished setting the date, press  to save your changes and return to the Status screen.

Displaying the Date

To display the current date, proceed as follows.

- 1 From the Status screen, press .
- 2 The current date and day of week displays in the following format.





JUN 21 11:00








Setting the Alarm

Your new pager allows you to set a daily alarm.

- 1 From the Status screen, press  until **SET ALARM** displays, and then press .



- 2 Press  to increase the hour. When the desired hour displays, press  to advance to the next field.
- 3 Repeat Step 2 to set the minutes and time of day (**A** or **P**).
- 4 Press  to toggle between **ON** and **OFF**. When the desired selection displays, press  to select it.
- 5 When you have finished setting the alarm, press  to save your changes and return to the Status screen.






Alerts



Setting the Alert Type

Your new pager has both audible and silent alert types. These alert types are: silent (vibrate), sleep (no alert), vibra call (vibrate then chirp), chirp, and eight standard audible alerts.

To specify the alert to play when your pager receives a message, proceed as follows:

- 1 From the Status screen, press  until **SET ALERT** displays, and press .







- 2 Press  to display the alert type and hear a sample of the alert.
- 3 When the desired alert type displays, press  to select it.







Reminder Alert


This feature allows you to turn on/off reminder alerts. Reminder alerts repeat at two-minute intervals until you have read all new messages. To turn on/off reminder alerts, proceed as follows:



- 1 From the Status screen, press  until **ADV CONTROL** displays, and then press . **REM ALERT** displays.
- 2 Press  to toggle between **ON** and **OFF**. Press  to make your selection.

Low Cell Alert

At the onset of a low battery condition, **LOW BATT** displays on the Status screen. You can also program your pager to emit an alert when your pager's battery is low.

- 1 From the Status screen, press  until **ADV CONTROL** displays, and then press .
- 2 Press  until **CELL ALERT** displays, and then press . The following screen displays.




- 3 Press  to toggle between *ON* and *OFF*, and press  to make your selection.
- The low cell alert repeats hourly between the hours of 8 a.m. and 8 p.m.







Messages

Your new Talkabout™ T10 pager can store up to 20 personal messages and 2 maildrop messages. If you have programmed your pager to alert you when it receives a message, an alert sounds (see “Setting the Alert Type” on page 12).

Reading Messages

❶ From the Status screen, press .





- When your pager receives an error message,  is appended to the end of the message when you display it.
- When your pager receives a group message, it emits an alert, and  displays.
- When your pager receives a maildrop message, it emits an alert, and  displays.









Locking/Unlocking Messages

You can lock up to ten messages to prevent them from being deleted or overwritten by new messages when the pager's memory is full.

- To lock a message, press  while the message displays.
- To unlock a message, press  while the locked message displays.

Message Information

When you receive a message, you can program your pager to display additional message information. To turn this feature on/off, proceed as follows:



- 1 From the Status screen, press  until *ADV CONTROL* displays, and then press .
- 2 Press  until *MSG INFO* displays, and then press .
- 3 Press  to toggle between *ON* and *OFF*, and press  to make your selection.



Deleting Messages




You can delete messages from your pager at any time. By deleting older messages, you decide which messages to keep and which to save before they are overwritten by new messages. (See also “Locking/Unlocking Messages” on page 16.)

Deleting an Individual Message

- 1 To delete an unlocked message, press  while the message is displayed.
 - To delete a locked message, you must first unlock the message. (See “Locking/Unlocking Messages” on page 16.)
- 2 Press  to confirm your decision.

Deleting All Messages

This feature allows you to delete all unlocked messages at once.

- 1 From the Status screen, press  until `DELETE ALL` displays, and then press .
- 2 When `DELETE ALL?` displays, press  to confirm your decision.



Care & Maintenance

The Talkabout™ T10 pagers are durable, reliable, and can provide years of dependable service; however, they are precision electronic products. Water and moisture, excessive heat, and extreme shock may damage the pager. Do not expose your pager to these conditions. If repair is required, the Motorola Service Organization, staffed with specially trained technicians, offers repair and maintenance facilities throughout the world.

For more information about warranties, please contact either your paging service provider, retailer, or Motorola, Inc. at 1-800-548-9954. For repairs, in the U.S., call Motorola, Inc. at 1-800-548-9954, in Canada, call 1-800-323-9685, in the U.K. and Ireland, call 01703-666-333. In the U.S., to contact Motorola, Inc. on your TTY, call 1-800-793-7834.



Cleaning Your Pager

To clean smudges and grime from the exterior of your pager, use a soft, non-abrasive cloth moistened in a mild soap and water solution. Use a second cloth moistened in clean water to wipe the surface clean. Do not immerse in water. Do not use alcohol or other cleaning solutions.



Questions

If you have any questions about the use of your Motorola pager, in the U.S. call 1-800-548-9954 or 1-800-793-7834 (TTY), in the U.K. call 0990-168556. If you have questions about your paging service, contact your paging service provider. For information about other Motorola products, please visit our web site at www.motorola.com.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the unit.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experience radio/ TV technician for help.

Motorola Limited Warranty

I. What this Warranty Covers and for How Long

The Motorola company listed below (Motorola) warrants this pager manufactured and/or sold by Motorola (Product) against defects in materials and workmanship under normal use for a period of one year from the date the Product is purchased by the first end-user purchaser.

Motorola, at its option, will at no charge either repair, replace, or refund the purchase price of any Product that does not conform with this warranty. Repair may include the replacement of parts with functionally equivalent reconditioned or new parts. Replacement may include providing a functionally equivalent "Motorola Certified Reconditioned/Refurbished/Pre-Owned" or new Product. Products that have been repaired or replaced are warranted for the balance of the original warranty period or for 90 days from the date that you received the repaired or replaced Product, whichever is longer. All Products and/or parts for which replacements have been provided become Motorola's property.

Motorola warrants that each copy of any software supplied with the Products will be free from physical defects in the media that tangibly embodies the copy for a period of 90 days from the date the Products are purchased by the first end-user purchaser.

Motorola, at its option, will at no charge repair

or replace the media of any such software that contains defects in materials or workmanship in the media. No updates are provided.

Motorola makes no representation that such software will meet your requirements or will work in combination with any hardware or applications software products provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in software products will be corrected.

This warranty extends to the first end-user purchaser only, and is not transferable.

II. Warranty Conditions

This warranty is valid only in the United States and Canada, and is Motorola's complete warranty for the Products. Motorola assumes no obligation or liability for changes to this warranty unless made in writing and signed by an officer of Motorola.

Motorola is not responsible in any way for any ancillary equipment not furnished by Motorola which is attached to or used in connection with the Products, or for operation of Products with any ancillary equipment, and all such equipment is expressly excluded from this warranty. Furthermore, Motorola is not responsible for any damage to Products resulting from the use of ancillary equipment not furnished by Motorola for use with the Products.

When Products are used in combination with ancillary or peripheral equipment not

manufactured or supplied by Motorola, Motorola does not warrant the operation of the combination, and Motorola will not honor a warranty claim in which the Product is used in such a combination and it is determined by Motorola there is no fault with the Product.

Motorola specifically disclaims any responsibility for any damaged caused in any way by the use of accessories and peripherals not manufactured or supplied by Motorola, including, but not limited to batteries, chargers adaptors, and power supplies.

Motorola does not warrant any installation, maintenance, or service that it did not perform. SERVICE WORK PERFORMED BY SERVICE CENTERS OR OTHERS NOT AUTHORIZED BY MOTOROLA TO PERFORM SUCH WORK WILL VOID THIS WARRANTY.

III. What this Warranty Does Not Cover

(a) Defects or damage resulting from: use of the Products in any manner not normal or customary, misuse, accident or neglect such as dropping the Products onto hard surfaces, contact with water, rain or extreme humidity, contact with sand, dirt or the like, contact with extreme heat, spills of food or liquid; improper testing, operation, maintenance, installation, adjustment, or any alteration or modification of any kind.

(b) This warranty does not extend to accessories, including nickel cadmium batteries, battery charger, or holsters, that accompany or are used with the Product.

(c) Physical damage to the surface of the Products, including scratches or other damage to displays, or other externally exposed parts.

(d) Products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.

(e) Products on which serial numbers or date tags have been removed, altered or obliterated.

(f) Products on which the board serial numbers do not match each other, or on which the board or serial numbers do not match the housing.

(g) Products with non-conforming or non-Motorola housings or parts.

(h) Failure of Products due primarily to any communication service or signal you may subscribe to or use with the Products.

FLAT RATE REPAIR RATES APPLY TO PRODUCTS NOT COVERED BY THIS WARRANTY.

IV. How to Get Warranty Service

To get warranty service, please call:

1-800-548-9954 USA, 1-800-461-4575

Canada, 1-800-793-7834 TTY.

You will receive directions on how to mail the Products to Motorola. All Products shipped to Motorola Service Centers must be shipped with freight and insurance prepaid. Along with the Products you must include a copy of your receipt, bill of sale, or some other comparable

proof of purchase, a written description of the problem, and, most importantly, your address, and telephone number. **RETAIN THE ORIGINAL OF YOUR PROOF OF PURCHASE.** Products that are repaired or replaced under this warranty will be shipped to you at Motorola's expense for the freight and insurance. If additional information is needed, please contact Motorola at the address at the bottom of this document.

V. General Provisions

THIS IS THE COMPLETE WARRANTY FOR THIS PRODUCT BY MOTOROLA AND SETS FORTH YOUR EXCLUSIVE REMEDIES.

THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER EXPRESS WARRANTIES. IMPLIED WARRANTIES INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE GIVEN ONLY IF SPECIFICALLY REQUIRED BY APPLICABLE LAW. OTHERWISE, THEY ARE SPECIFICALLY EXCLUDED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR FINANCIAL LOSS ARISING OUT OF OR IN

CONNECTINO WITH THE USE OF INABILITY TO USE THE PRODUCT, TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

VI. Patent and Software Provisions

Motorola will defend at it own expense, any suit brought against you to the extent that it is based on a claim that the Products infringe a United States patent. Motorola will pay those costs and damages finally awarded against yo in any such suit which is attributable to any such claim. The defense and payments by Motorola are conditioned on the following: (a) that you will notify Motorola promptly in writing any notice of the claim, and (b) that Motorola will have sole control of the defense of the suit and all negotiations for its settlement or compromise, and (c) should the Products become, or in Motorola's opinion be likely to become, the subject of a claim of infringement of a United States patent, that you will permit Motorola, at its option and expense, either: to procure for you the right to continue using the Products or parts; to replace or modify them so that they become non-infringing; or to grant you a credit for such Products or parts as depreciated and accept their return. The depreciation will be an equal amount per year over the lifetime of the Products, accessories, battery or parts as established by Motorola. Motorola will have no liability to you with respect to any claim of patent infringement which is based upon the combination of the

Products or parts furnished under this limited warranty with software, apparatus or devices not furnished by Motorola. Motorola will have no liability for the use of ancillary or peripheral equipment or software not furnished by Motorola which is attached to or used in connection with the Products. The foregoing states the entire liability of Motorola with respect to infringement of patents by the Products, accessories, batteries or any parts of them.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce in copies and distribute copies of the Motorola software. Motorola software may be copied into, used in and redistributed with only the Products associated with such Motorola software. No other use, including without limitation disassembly or reverse engineering, of such Motorola software or exercise of exclusive rights in such Motorola software is permitted.

VII. State Law and Other Jurisdiction Rights

Some states and other jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction. Call first for

information on obtaining warranty service. If you otherwise need to correspond with Motorola about this Product, write to:
In the USA:

Motorola, Inc.
1500 Gateway Blvd.
Boynton Beach, FL
USA 33426-8292
1-800-548-9954 USA
1-800-793-7834 TTY

In Canada:
Motorola Canada Limited
5875 Whittle Road
Mississauga, ON L4Z 2H4
1-800-461-4575

MOTOROLA LIMITED WARRANTY

NOTES

Personal Numbers

Use the spaces provided below to write down your pager and personal identification number (PIN), and the number of your service provider. Additional spaces have been provided to write down the pager and PIN of your family and friends.

Service Provider

Pager # and PIN

Family and Friends

Pager # and PIN



Talkabout 10	A05 Models
	A05 Modèles
FC	Tested to Comply
	With FCC Standards
	Testé afin d'être conforme
	aux normes de la FCC
FOR HOME OR OFFICE USE	
POUR UTILISATION À	
LA MAISON OU AU BUREAU	

MOTOROLA, the Stylized M Logo, and all other trademarks indicated as such herein are trademarks of Motorola, Inc.

® Reg. U.S. Pat. & Tm. Off.

© 2000 Motorola, Inc. All rights reserved.

MOTOROLA, le logo M stylisé et toutes les autres marques de commerce mentionnées ici appartiennent à Motorola, Inc.

® Marques de commerce et brevets déposés aux É.-U.

© 2000 Motorola, Inc.

Tous droits réservés.

Personal Communications Sector

1500 Gateway Blvd., Boynton Beach, FL 33426-8292

Printed in Singapore 8/00

Imprimé aux Singapour 8/00



6881036B50-O